TOP AND CONSOLE PARTS

ELECTRIC DRYER

For Model: LER3624EQ1

(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: LER3624EQ1

(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	3397545	Panel, Rear Console
2	693995	Screw, Hex Head
3	3390646	Screw, 8−18 x 5/16
4	3358528	Cap, End (L.H.)
5	3936144	Connector
6	388326	Screw, Console
7	3400859	Screw, Grounding
8	3358513	Cap, End (R.H.)
10	339392	Screen, Lint
11		Cover, Lint Screen
	688150	White
12	339229	Hinge, R.H.
	339230	Hinge, L.H.
13	688983	Screw, 8−18 x 5/8
14	94614	Terminal
15	3395683	Connector (Motor)
16		Top
	3396022	White
18	3394427	Clip, Harness
19	3401076	Resistor Assembly
21	3976568	Timer, 60 Hz.
30	357213	Nut, Push−In (2)
31	3394292	Harness, Wiring
39	3395382	Switch, Push−To−Start
48	3406143	Timer Knob Assembly
53	8054298	Bracket, Control
54	3976746	Panel, Control
81	3406133	Knob, Push To Start

LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION
LITERATURE PARTS		
	LIT3406071	Guide, Use & Care
	LIT3397618	Instructions, Installation
	LIT3406688	Label, Wiring Diagram
OPTIONAL PARTS NOT INCLUDED		
PAINT, TOUCH−UP (1/2oz.)		
	72017	White
	72107	Almond
PAINT, PRESSURIZED SPRAY (13 oz.)		
	350930	White
	350956	Almond
	350938	Primer, Gray
PAINT, BULK (1 qt.)		
	799344	White (Uncut)
	978883	Almond (Uncut)

CABINET PARTS

For Model: LER3624EQ1

(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Model: LER3624EQ1

(Designer White)

Illus. No.	Part No.	DESCRIPTION
2	3393008	Screw, 10−16 x 1/2
4	343641	Screw, 10−16 x 1/2
5	3396795	Cover, Terminal Block
7	3396807	Panel, Rear
8	694091	Screw, 8−18 x 3/8
10	3406102	Door Switch Assembly
11	697773	Screw, 6−20 x 7/8
13	693995	Screw, Hex Washer Head
16	3392100	Foot, Dryer (4)
18		Cabinet Assembly (Includes Illus. Nos. 5, 7, 16, 29, 41 & 57)
	3399580	White
19	98234	Clip, Ground
20	690363	Lock, Front Top (2)
21		Front Panel Assembly
	693197	White
23	685203	Clip, Felt Pad
24	3389441	Catch, Door
28	348023	Hinge and Pin Assembly (2)
29	3394083	Clip, Front Panel (2)
33	696144	Strike, Door
35	695656	Door, Rear
36		Door Front
	348205	White
37		Handle, Door
	686711	White
38	349462	Seal & Bearing Assembly
40	279393	Terminal Block Kit For Terminal Block
41	3397659	Block, Terminal
51	238088	Hinge, Top (2)
53	691366	Idler & Pulley Assembly
56	660996	Belt, Drive
57	348780	Base, Motor
58	3400500	Bolt, 5/16−18 x 3/4
59	3401143	Pulley, 60 Hz.
62	3395652	Motor Assembly 60 Hz.
63	660658	Clamp, Motor
64	3404162	Clamp, Motor (W/Shield)
67	3390734	Seal, Door
87	697776	Screw, 10−32 x 1/2 (External Ground)
90	279318	Terminal, Tinned & Brass (3) (Includes Illus. 40)

BULKHEAD PARTS

For Model: LER3624EQ1

(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	694283	Lint Chute Assembly
2	489463	Screw
4	3388703	Washer, Support
5	90767	Screw, 8 x 3/8
6	3399848	Thermal Cut−Off (Hi−Limit Thermostat Illus. No.15 Included)
7	347139	Seal, Lint Chute
9	3392247	Pad, Blower Housing
10	694089	Wheel, Blower
11	3405016	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10−16 x 1/2
14	3397566	Box, Heater
15	3399693	Thermostat, 250°F (121.1C)
16	3394196	Seal, Blower Shaft
17	3403585	Element, Heater
21	279457	Wire Kit (For Heater Element Wiring Harness Repair)
23	3392519	Fuse, Thermal
24	660039	Thermostat, 150°F (66°C)
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8−16
48	3397264	Bulkhead
62	3394508	Ring, Bearing
63	97787	Screw, 11−16 x 7/8
66	337449	Seal, Rear Drum
67	3396775	Drum Assembly
68	342847	Baffle, Drum
69	3976435	Bracket, Support
70	90296	Clip
73	339956	Seal
75	696302	Shield, Exhaust

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST